



**YAMAHA**

**2002**

**YFA1(P)**

**3FA-AE1**

**SUPPLEMENTARY  
SERVICE MANUAL**



---

## **FOREWORD**

This Supplementary Service Manual has been prepared to introduce new service and new data for the YFA1(P) 2002. For complete information on service procedures, it is necessary to use this Supplementary Service Manual together with the following manual.

**YFA1W SERVICE MANUAL: 3FA-ME1**

**YFA1(P) 2002  
SUPPLEMENTARY  
SERVICE MANUAL**

**© 2001 by Yamaha Motor Co., Ltd.**

**First Edition, May 2001**

**All rights reserved.**

**Any reproduction or unauthorized use  
without the written permission of  
Yamaha Motor Co., Ltd.  
is expressly prohibited.**

---

## NOTICE

This manual was produced by the Yamaha Motor Company primarily for use by Yamaha dealers and their qualified mechanics. It is not possible to include all the knowledge of a mechanic in one manual, so it is assumed that anyone who uses this book to perform maintenance and repairs on Yamaha machine has a basic understanding of the mechanical ideas and the procedures of machine repair. Repairs attempted by anyone without this knowledge are likely to render the machine unsafe and unfit for use.

Yamaha Motor Company, Ltd. is continually striving to improve all its models. Modifications and significant changes in specifications or procedures will be forwarded to all authorized Yamaha dealers and will appear in future editions of this manual where applicable.

**NOTE:**

---

Designs and specifications are subject to change without notice.

---

## IMPORTANT INFORMATION

Particularly important information is distinguished in this manual by the following notations.



The Safety Alert Symbol means ATTENTION! BECOME ALERT! YOUR SAFETY IS INVOLVED!

**WARNING**

Failure to follow WARNING instructions could result in severe injury or death to the machine operator, a bystander or a person inspecting or repairing the machine.

**CAUTION:**

A CAUTION indicates special precautions that must be taken to avoid damage to the machine.

**NOTE:**

A NOTE provides key information to make procedures easier or clearer.

# HOW TO USE THIS MANUAL

## CONSTRUCTION OF THIS MANUAL

This manual consists of chapters for the main categories of subjects. (See “Illustrated symbols”)

- 1st title ①: This is a chapter with its symbol on the upper right of each page.
- 2nd title ②: This title appears on the upper of each page on the left of the chapter symbol. (For the chapter “Periodic inspection and adjustment” the 3rd title appears.)
- 3rd title ③: This is a final title.

## MANUAL FORMAT

All of the procedures in this manual are organized in a sequential, step-by-step format. The information has been compiled to provide the mechanic with an easy to read, handy reference that contains comprehensive explanations of all disassembly, repair, assembly, and inspections.


A set of particularly important procedure ④ is placed between a line of asterisks “\*” with each procedure preceded by “●”.

























## IMPORTANT FEATURES

- Data and a special tool are framed in a box preceded by a relevant symbol ⑤.
- An encircled numeral ⑥ indicates a part name, and an encircled alphabetical letter data or an alignment mark ⑦, the others being indicated by an alphabetical letter in a box ⑧.
- A condition of a faulty component will precede an arrow symbol ⑨ and the course of action will follow it.

## EXPLODED DIAGRAM

Each chapter provides exploded diagrams before each disassembly section for ease in identifying correct disassembly and assembly procedures.



① GEN INFO 	② SPEC 		
③ CHK ADJ 	④ ENG 		
⑤ CARB 	⑥ DRIV 		
⑦ CHAS 	⑧ ELEC 		
⑨ TRBL SHTG ? 	⑩ 		
⑪ 	⑫ 		
⑬ 	⑭ 		
⑮ 	⑯ 		
⑰ 	⑱ 	⑲ 	
⑳ 	㉑ 	㉒ 	㉓ 
㉔ 	㉕ <b>New</b>		

EB003000

## ILLUSTRATED SYMBOLS

Illustrated symbols ① to ⑨ are printed on the top right of each page and indicate the subject of each chapter.

- ① General information
- ② Specifications
- ③ Periodic checks and adjustments
- ④ Engine
- ⑤ Carburetion
- ⑥ Drive train
- ⑦ Chassis
- ⑧ Electrical
- ⑨ Troubleshooting

Illustrated symbols ⑩ to ⑯ are used to identify the specifications appearing in the text.

- ⑩ Filling fluid
- ⑪ Lubricant
- ⑫ Special tool
- ⑬ Torque
- ⑭ Wear limit, clearance
- ⑮ Engine speed
- ⑯ Ω, V, A

Illustrated symbols ⑰ to ㉓ in the exploded diagrams indicate the types of lubricants and lubrication points.

- ⑰ Apply engine oil
- ⑱ Apply gear oil
- ⑲ Apply molybdenum disulfide oil
- ⑳ Apply wheel bearing grease
- ㉑ Apply lightweight lithium soap base grease
- ㉒ Apply molybdenum disulfide grease
- ㉓ Apply silicon grease

Illustrated symbols ㉔ to ㉕ in the exploded diagrams indicate where to apply a locking agent ㉔ and when to install a new part ㉕.

- ㉔ Apply the locking agent (LOCTITE®)
- ㉕ Replace


---

# CONTENTS

<b>GENERAL INFORMATION</b> .....	1
MACHINE IDENTIFICATION .....	1
MODEL LABEL .....	1
<b>SPECIFICATIONS</b> .....	2
GENERAL SPECIFICATIONS .....	2
MAINTENANCE SPECIFICATIONS .....	3
ENGINE .....	3
CHASSIS .....	5
ELECTRICAL .....	6
CABLE ROUTING .....	8
<b>PERIODIC CHECKS AND ADJUSTMENTS</b> .....	14
INTRODUCTION .....	14
PERIODIC MAINTENANCE/LUBRICATION INTERVALS .....	14
CHASSIS .....	15
ADJUSTING THE FRONT BRAKE .....	15
<b>CHASSIS</b> .....	16
STEERING SYSTEM .....	16
<b>ELECTRICAL</b> .....	17
CHECKING THE SWITCH .....	17
CHECKING THE SWITCH .....	17
CHECKING A SWITCH SHOWN IN THE MANUAL .....	17
SIGNAL SYSTEM .....	18
CIRCUIT DIAGRAM .....	18
CHECKING THE SIGNAL SYSTEM .....	19
<b>YFA1(P) 2002 WIRING DIAGRAM</b>	







**GENERAL INFORMATION**  
**MACHINE IDENTIFICATION**

**MODEL LABEL**

The model label ① is affixed to the frame. This information will be needed to order spare parts.



## SPECIFICATIONS







## GENERAL SPECIFICATIONS

Model	YFA1 (P) 2002
Model code number	3FAY (CDN, Europe and Oceania)
Engine:	
Engine type	Air-cooled 4-stroke, SOHC
Cylinder arrangement	Forward-inclined single cylinder
Displacement	124 cm <sup>3</sup>
Bore × stroke	49 × 66 mm (1.93 × 2.60 in)
Compression ratio	9.0 : 1
Compression pressure	850 kPa (8.5 kg/cm <sup>2</sup> , 121 psi) at 570 r/min
Starting system	Electric starter
Transmission:	
Primary reduction system	Helical gear/spur gear
Primary reduction ratio	43/14 × 40/17 (7.226)
Secondary reduction system	Chain drive
Secondary reduction ratio	32/12 (2.666)
Clutch type	Dry, centrifugal automatic
Transmission type	Single speed automatic (V-belt)
Operation	Centrifugal automatic type
Single speed automatic	2.303 ~ 0.821
Reverse ratio	49/14 × 49/15 × 40/17 (26.902)
Tire:	
Type	Tubeless
Size	
Front	AT20 × 7-8
Rear	AT22 × 10-8
Manufacturer (type)	
Front	DUNLOP (KT536A)
Rear	DUNLOP (KT537A)
Wear limit	3.0 mm (0.12 in)
Electrical:	
Ignition system	CDI
Generator system	A.C. magneto generator
Battery capacity	12 V 12 AH
Battery type	12N12C-4A-2
Headlight type	Bulb type
Headlight bulb type	Incandescence
Bulb wattage (quantity)	
Headlight	12 V 25 W/25 W (1 pc.)
Tail/brake light	12 V 5 W/21 W (1 pc.)
Neutral indicator light	12 V 3.4 W (1 pc.)
Reverse indicator light	12 V 3.4 W (1 pc.)







MAINTENANCE SPECIFICATIONS

ENGINE

Model	YFA1 (P) 2002
<p>Cylinder:</p> <p>Bore size</p> <p>&lt;Wear limit&gt;</p> <p>Measuring point “*”</p> 	<p>48.99 ~ 49.03 mm (1.9287 ~ 1.9303 in)</p> <p>&lt;49.15 mm (1.935 in)&gt;</p> <p>45 mm (1.77 in)</p>
<p>Camshaft:</p> <p>Drive method</p> <p>Cam dimensions</p> <p>Intake “A”</p> <p>“B”</p> <p>“C”</p> <p>Exhaust “A”</p> <p>“B”</p> <p>“C”</p> <p>Camshaft runout limit</p> 	<p>Chain drive (left)</p> <p>26.169 ~ 26.269 mm (1.0303 ~ 1.0342 in)</p> <p>21.061 ~ 21.161 mm (0.8292 ~ 0.8331 in)</p> <p>5.159 ~ 5.279 mm (0.2031 ~ 0.2078 in)</p> <p>26.169 ~ 26.269 mm (1.0303 ~ 1.0342 in)</p> <p>21.061 ~ 21.161 mm (0.8292 ~ 0.8331 in)</p> <p>5.159 ~ 5.279 mm (0.2031 ~ 0.2078 in)</p> <p>0.03 mm (0.0012 in)</p>
<p>Rocker arm/rocker arm shaft:</p> <p>Inside diameter (rocker arm)</p> <p>Outside diameter (shaft)</p> <p>Arm-to-shaft clearance</p>	<p>10.000 ~ 10.015 mm (0.3937 ~ 0.3943 in)</p> <p>9.981 ~ 9.991 mm (0.3930 ~ 0.3933 in)</p> <p>0.009 ~ 0.034 mm (0.0004 ~ 0.0013 in)</p>
<p>Valve, valve seat, valve guide:</p> <p>Valve clearance (cold)</p> <p>Intake</p> <p>Exhaust</p> <p>Valve dimensions</p> <p>“A” head diameter</p> <p>Intake</p> <p>Exhaust</p>  <p>“B” face width</p> <p>Intake</p> <p>Exhaust</p>  <p>“C” seat width</p> <p>Intake</p> <p>Exhaust</p>  <p>“D” margin thickness</p> <p>Intake</p> <p>Exhaust</p>  <p>Outside diameter (valve stem)</p> <p>Intake</p> <p>Exhaust</p>	<p>0.08 ~ 0.12 mm (0.0031 ~ 0.0047 in)</p> <p>0.10 ~ 0.14 mm (0.0039 ~ 0.0055 in)</p> <p>25.9 ~ 26.1 mm (1.02 ~ 1.03 in)</p> <p>21.9 ~ 22.1 mm (0.86 ~ 0.87 in)</p> <p>1.4 ~ 3.0 mm (0.06 ~ 0.12 in)</p> <p>1.7 ~ 2.8 mm (0.07 ~ 0.11 in)</p> <p>0.9 ~ 1.1 mm (0.035 ~ 0.043 in)</p> <p>0.9 ~ 1.1 mm (0.035 ~ 0.043 in)</p> <p>0.4 ~ 0.8 mm (0.016 ~ 0.031 in)</p> <p>0.8 ~ 1.2 mm (0.031 ~ 0.047 in)</p> <p>4.975 ~ 4.990 mm (0.196 in)</p> <p>4.960 ~ 4.975 mm (0.195 ~ 0.196 in)</p>



Model	YFA1 (P) 2002
Inside diameter (valve guide) Intake Exhaust Stem-to-guide clearance Intake Exhaust Stem runout limit Valve seat width Intake Exhaust	5.000 ~ 5.012 mm (0.197 in) 5.000 ~ 5.012 mm (0.197 in) 0.010 ~ 0.037 mm (0.004 ~ 0.0014 in) 0.025 ~ 0.052 mm (0.0010 ~ 0.0020 in) 0.01 mm (0.0004 in) 0.9 ~ 1.1 mm (0.035 ~ 0.043 in) 0.9 ~ 1.1 mm (0.035 ~ 0.043 in)
Piston: Piston size "D" Measuring point "H"  Piston-to-cylinder clearance <Wear limit> Over size    2nd 4th Piston off-set Piston off-set direction Inside diameter (piston pin bore) Outside diameter (piston pin) Piston pin-to-piston clearance <Limit>	48.96 ~ 49.00 mm (1.927 ~ 1.929 in) 6 mm (0.24 in) From bottom of the piston. 0.020 ~ 0.040 mm (0.0008 ~ 0.0016 in) <0.15 mm (0.006 in)> 49.5 mm (1.95 in) 50.0 mm (1.97 in) 0.5 mm (0.02 in) Intake side 13.002 ~ 13.013 mm (0.5119 ~ 0.5123 in) 12.996 ~ 13.000 mm (0.5117 ~ 0.5118 in) 0.002 ~ 0.017 mm (0.0001 ~ 0.0006 in) <0.07 mm (0.003 in)>
Piston ring: Type Top ring 2nd ring Dimension (B × T) Top ring  Second ring  Oil ring  End gap (installed) Top ring Second ring Oil ring	Barrel Taper 1.0 × 2.0 mm (0.039 × 0.079 in) 1.0 × 2.0 mm (0.039 × 0.079 in) 2.0 × 2.2 mm (0.079 × 0.087 in) 0.15 ~ 0.30 mm (0.006 ~ 0.012 in) 0.15 ~ 0.30 mm (0.006 ~ 0.012 in) 0.20 ~ 0.80 mm (0.008 ~ 0.031 in)



Model	YFA1 (P) 2002
Side clearance	
Top ring	0.03 ~ 0.07 mm (0.0012 ~ 0.0027 in)
Second ring	0.02 ~ 0.06 mm (0.0008 ~ 0.0024 in)
Carburetor:	
I.D. mark	3FA02
Main jet (M.J.)	#82.5
Main air jet (M.A.J.)	ø1.3
Jet needle (J.N.)	4H36-3
Needle jet (N.J.)	N-6
Cutaway (C.A.)	2.5
Pilot air jet (P.A.J.)	#130
Pilot outlet (P.O.)	ø0.7
Pilot jet (P.J.)	#12.5
Bypass 1 (B.P1)	1.1
Pilot screw (P.S.)	2 and 1/2 turns out
Valve seat size (V.S.)	1.8
Starter jet (G.S.)	#45
Float height (F.H.)	21.8 mm (0.858 in)
Fuel level (F.L.)	4.0 ~ 6.0 mm (0.16 ~ 0.24 in)
	With special tool
Engine idling speed	1,650 ~ 1,750 r/min
Intake vacuum	26.7 kPa (200 mm Hg, 7.88 in Hg)

**CHASSIS**

Model	YFA1 (P) 2002
Suspension:	
Suspension travel	
Front	41 mm (1.614 in)
Rear	60 mm (2.362 in)
Free length (spring)	
Front	148 mm (5.827 in)
Rear	205 mm (8.071 in)
Installed length	
Rear	180 mm (7.09 in)
Spring rate	
Front	29.4 N/mm (3.0 kg/mm, 167.9 lb/in)
Rear	36.3 N/mm (3.7 kg/mm, 207.3 lb/in)
Stroke	
Front	0.0 ~ 41 mm (0.0 ~ 1.614 in)
Rear	0.0 ~ 60 mm (0.0 ~ 2.362 in)
Optional spring	
Front	No
Rear	No



Model	YFA1 (P) 2002
<b>Drive chain:</b> Type/manufacturer Number of links Chain slack 10-link length limit	520V6/DAIDO 74 links 30 mm (1.18 in) 150.1 mm (5.909 in)
<b>Brake lever:</b> Free play Front brake  Rear brake	5 ~ 8 mm (0.20 ~ 0.31 in) At lever pivot.  5 ~ 8 mm (0.20 ~ 0.31 in) At lever pivot.

### ELECTRICAL

Model	YFA1 (P) 2002
<b>C.D.I.:</b> Magneto model/manufacturer Pickup coil resistance (lead color) C.D.I. unit model/manufacturer	F3FA/YAMAHA 248 ~ 372 Ω at 20 °C (68 °F) (White–Red) 3FA/YAMAHA
<b>Ignition coil:</b> Model/manufacturer Minimum spark gap Primary coil resistance Secondary coil resistance	2JN/YAMAHA 6.0 mm (0.24 in) 0.18 ~ 0.28 Ω at 20 °C (68 °F) 6.32 ~ 9.48 kΩ at 20 °C (68 °F)
<b>Spark plug cap:</b> Material Resistance	Resin 10 kΩ at 20 °C (68 °F)
<b>Charging system:</b> Type Magneto model/manufacturer Charging coil resistance (lead color) Charging current Day (Minimum) (Maximum) Night (Minimum) (Maximum) Lighting coil resistance (lead color) Lighting voltage (Minimum) (Maximum) Standard output	A.C. magneto generator F3FA/YAMAHA 0.96 ~ 1.44 Ω at 20 °C (68 °F) (Black–White)  0.8 A at 3,000 r/min 2.0 A at 8,000 r/min  0.6 A at 3,000 r/min 3.5 A at 8,000 r/min  0.72 ~ 1.08 Ω at 20 °C (68 °F) (Black–Yellow)  12.0 V at 3,000 r/min 14.8 V at 8,000 r/min  14 V 125 W at 5,000 r/min




Model	YFA1 (P) 2002
<p>Rectifier/regulator:</p> <p>Model/manufacturer</p> <p>Regulator type</p> <p>No load regulated voltage (DC)</p> <p>No load regulated voltage (AC)</p> <p>Rectifier capacity (DC)</p> <p>Rectifier capacity (AC)</p> <p>Withstand voltage</p>	<p>EHU-01TR31/MATSUSHITA</p> <p>Semi conductor short circuit type</p> <p>14.0 ~ 15.0 V</p> <p>13.0 ~ 14.0 V</p> <p>8.0 A</p> <p>8.0 A</p> <p>200 V</p>
<p>Electric starting system:</p> <p>Type</p> <p>Starter motor</p> <p>Model/manufacturer</p> <p>Output</p> <p>Armature coil resistance</p> <p>Overall length (brush)</p> <p>&lt;Limit&gt;</p> <p>Brush spring pressure</p> <p>Commutator diameter</p> <p>&lt;Wear limit&gt;</p> <p>Mica undercut</p> <p>Starter relay</p> <p>Model/manufacturer</p> <p>Amperage rating</p> <p>Coil resistance</p> <p>Starting circuit cut-off relay</p> <p>Model/manufacturer</p> <p>Coil resistance</p> <p>Diode</p>	<p>Constant mesh</p> <p>3FA1/YAMAHA</p> <p>0.4 kW</p> <p>0.019 ~ 0.023 Ω at 20 °C (68 °F)</p> <p>10.0 mm (0.39 in)</p> <p>&lt;3.5 mm (0.14 in)&gt;</p> <p>552 ~ 828 g</p> <p>22.0 mm (0.87 in)</p> <p>&lt;21.0 mm (0.83 in)&gt;</p> <p>1.5 mm (0.06 in)</p> <p>MS5D-611/JIDECO</p> <p>100 A</p> <p>3.87 ~ 4.73 Ω at 20 °C (68 °F)</p> <p>ACA1211-9/MATSUSHITA</p> <p>72 ~ 88 Ω at 20 °C (68 °F)</p> <p>No</p>



## CABLE ROUTING

- ① Throttle cable
- ② Band
- ③ Breather hose
- ④ Rear brake switch lead
- ⑤ Rear brake cable
- ⑥ Front brake cable
- ⑦ Front brake switch lead








- ① Front brake cable
- ② Band
- ③ Rear brake cable
- ④ Rear brake switch lead
- ⑤ CDI unit
- ⑥ Wire harness
- ⑦ Main switch
- ⑧ Front brake switch lead


- A Pass leads in front of the brake cable and connect them inside the headlight body.
- B Pass the inlet and outlet hoses between the brake cables.
- C Clamp the front brake switch lead, rear brake switch lead, main switch lead, handlebar switch lead, and wire sub-leads with a plastic clamp.
- D Pass the leads between the throttle cable and front brake cable.





- ① Throttle cable
- ② Rectifier/regulator
- ③ Starting motor
- ④ CDI magneto lead
- ⑤ Clamp
- ⑥ Ignition coil


A Fasten the wire harness, starting motor lead and transmission case breather hose to the frame with a plastic band.





- ① Taillight
- ② Reverse relay
- ③ Starting circuit cut-off relay
- ④ Fuse holder
- ⑤ Starter relay
- ⑥ Wire harness
- ⑦ Breather hose (transmission case)
- ⑧ Neutral switch lead
- ⑨ Select lever switch
- ⑩ Overflow hose
- ⑪ Battery breather hose
- ⑫ Band


- ⑬ Battery negative lead
- ⑭ Reverse switch lead
- [A] Hold the clamp and ground lead to the crank-case with a screw.
- [B] Pass the overflow hose between the engine and swingarm.
- [C] Pass the battery breather hose through the guides.





- ① Inlet hose
- ② Outlet hose
- ③ Fuel hose
- ④ Breather hose (crankcase)
- ⑤ Overflow hose
- ⑥ Guide
- ⑦ Rear brake cable
- ⑧ Front brake cable (left)
- ⑨ Front brake cable (right)
- ⑩ CDI unit
- ⑪ Band

- A** Pass the breather hose through the hole of handlebar cover and then between the steering column and fuel tank.
- B** Pass the overflow hose left side of the engine stay.
- C** Pass the brake cable inside the swingarm.






- ① CDI unit
- ② Band
- ③ Starter cable
- ④ Wire harness
- ⑤ Breather hose (transmission case)
- ⑥ Ignition coil
- ⑦ Battery positive lead
- ⑧ Battery negative lead
- ⑨ Breather hose (crankcase)
- ⑩ Throttle cable
- ⑪ Fuse holder
- ⑫ Starting circuit cut-off relay

- ⑬ Reverse relay

**A** Pass the breather hose between the throttle cable and starter cable.



EB300000

## PERIODIC CHECKS AND ADJUSTMENTS

### INTRODUCTION

This chapter includes all information necessary to perform recommended inspections and adjustments. These preventive maintenance procedures, if followed, will ensure more reliable vehicle operation and a longer service life. The need for costly overhaul work will be greatly reduced. This information applies to vehicles already in service as well as to new vehicles that are being prepared for sale. All service technicians should be familiar with this entire chapter.



EB301000

### PERIODIC MAINTENANCE/LUBRICATION INTERVALS

ITEM	ROUTINE	INITIAL			EVERY	
		1 month	3 months	6 months	6 months	1 year
<b>Valves*</b>	<ul style="list-style-type: none"> <li>• Check valve clearance.</li> <li>• Adjust if necessary.</li> </ul>	○		○	○	○
<b>Spark plug</b>	<ul style="list-style-type: none"> <li>• Check condition.</li> <li>• Adjust gap and clean.</li> <li>• Replace if necessary.</li> </ul>	○	○	○	○	○
<b>Air filter element (for engine and V-belt compartment)</b>	<ul style="list-style-type: none"> <li>• Clean.</li> <li>• Replace if necessary.</li> </ul>	Every 20 ~ 40 hours (More often in wet or dusty areas.)				
<b>Carburetor*</b>	<ul style="list-style-type: none"> <li>• Check idle speed/starter operation.</li> <li>• Adjust if necessary.</li> </ul>		○	○	○	○
<b>Cylinderhead cover breather system*</b>	<ul style="list-style-type: none"> <li>• Check breather hose for cracks or damage.</li> <li>• Replace if necessary.</li> </ul>			○	○	○
<b>Exhaust system*</b>	<ul style="list-style-type: none"> <li>• Check leakage.</li> <li>• Retighten if necessary.</li> <li>• Replace gasket if necessary.</li> </ul>			○	○	○
<b>Fuel line*</b>	<ul style="list-style-type: none"> <li>• Check fuel hose for cracks or damage.</li> <li>• Replace if necessary.</li> </ul>			○	○	○
<b>Engine oil</b>	<ul style="list-style-type: none"> <li>• Replace (Warm engine before draining).</li> </ul>	○		○	○	○
<b>Oil strainer*</b>	<ul style="list-style-type: none"> <li>• Clean.</li> <li>• Replace if necessary.</li> </ul>	○		○		○
<b>Drive chain</b>	<ul style="list-style-type: none"> <li>• Check and adjust slack/alignment/clean/lube.</li> </ul>	○	○	○	○	○
<b>Transmission oil</b>	<ul style="list-style-type: none"> <li>• Check oil level/oil leakage.</li> <li>• Replace every 12 months.</li> </ul>	○				○
<b>Brakes*</b>	<ul style="list-style-type: none"> <li>• Check operation.</li> <li>• Adjust if necessary.</li> </ul>	○	○	○	○	○
<b>V-belt*</b>	<ul style="list-style-type: none"> <li>• Check operation.</li> <li>• Replace if damage or excessive wear.</li> </ul>	○				○
<b>Wheels*</b>	<ul style="list-style-type: none"> <li>• Check balance/damage/runout.</li> <li>• Replace if necessary.</li> </ul>	○		○	○	○
<b>Wheel bearings*</b>	<ul style="list-style-type: none"> <li>• Check bearing assembly for looseness or damage.</li> <li>• Replace if necessary.</li> </ul>	○		○	○	○
<b>Steering system*</b>	<ul style="list-style-type: none"> <li>• Check operation.</li> <li>• Replace if damaged.</li> <li>• Check toe-in.</li> <li>• Adjust if necessary.</li> </ul>	○	○	○	○	○
<b>Knuckle shafts/Steering shaft*</b>	<ul style="list-style-type: none"> <li>• Lubricate every 6 months.**</li> </ul>			○	○	○
<b>Fittings and Fasteners*</b>	<ul style="list-style-type: none"> <li>• Check all chassis fittings and fasteners.</li> <li>• Correct if necessary.</li> </ul>	○	○	○	○	○
<b>Battery*</b>	<ul style="list-style-type: none"> <li>• Check specific gravity.</li> <li>• Check breather hose for proper operation.</li> <li>• Correct if necessary.</li> </ul>	○	○	○	○	○

\* It is recommended that these items be serviced by a Yamaha dealer.

\*\* Lithium-soap-based grease



## CHASSIS

### ADJUSTING THE FRONT BRAKE

1. Check:

- Front brake lever free play ③
- Out of specification → Adjust.

**Front brake lever free play:**  
5 ~ 8 mm (0.20 ~ 0.3 in) at lever pivot

2. Adjust:

- Front brake lever free play

\*\*\*\*\*

- Loosen the locknut ①.
- Turn the adjuster ② in or out until the specified brake lever free play is obtained.

Turning in	Free play is increased.
Turning out	Free play is decreased.

- Tighten the locknut.

**CAUTION:**


**After adjusting the brake lever free play, make sure there is no drag.**

\*\*\*\*\*



CHASSIS

STEERING SYSTEM

- ① Handlebar holder (upper)
- ② Handlebar holder (lower)
- ③ Steering column
- ④ Cable joint
- ⑤ Cable joint bracket
- ⑥ Collar
- ⑦ Steering bracket
- ⑧ Oil seal
- ⑨ Steering bracket
- ⑩ Steering knuckle
- ⑪ Tie-rod







**ELECTRICAL**

**CHECKING THE SWITCH**


**CHECKING THE SWITCH**

Use a pocket tester to check the terminals for continuity. If the continuity is faulty at any point, replace the switch.

	<b>Pocket tester:</b>
	<b>P/N. YU-03112, 90890-03112</b>

**NOTE:**

- Set the pocket tester to “0” before starting the test.
- The pocket tester should be set to the “Ω × 1” range when testing the switch for continuity.
- Turn the switch on and off a few times when checking it.



**CHECKING A SWITCH SHOWN IN THE MANUAL**

The terminal connections for switches (main switch, handlebar switch, engine stop switch, light switch, etc.) are shown in a chart similar to the one on the left.

This chart shows the switch positions in the column and the switch lead colors in the top row.

For each switch position, “○—○” indicates the terminals with continuity.


**The example chart shows that:**

- ① There is continuity between the “Red and Brown” leads when the switch is set to “ON”.




EB806000

**SIGNAL SYSTEM  
CIRCUIT DIAGRAM**



- ③ Main switch
- ④ Fuse
- ⑤ Battery
- ⑨ CDI unit
- ⑫ Neutral indicator light
- ⑬ Neutral switch
- ⑭ Select lever switch
- ⑮ Reverse indicator light
- ⑯ Reverse relay
- ⑰ Reverse switch
- ⑱ Front brake light switch
- ⑲ Tail/brake light
- ⑳ Engine stop switch



**CHECKING THE SIGNAL SYSTEM**

1.If the tail/brake light fails to come on:

1.Bulb and bulb socket  
 • Check the bulb and bulb socket for continuity.



NO CONTINUITY



Replace the bulb and/or bulb socket.

2.Brake light switches  
 Refer to "CHECKING THE SWITCH".




NO CONTINUITY



Replace the brake switch.

3.Voltage  
 • Connect the pocket tester (DC 20V) to the bulb socket connector.  
**Tester (+) lead → Yellow terminal ①**  
**Tester (-) lead → Black terminal ②**



• Turn the main switch to "ON".  
 • Check the voltage (12 V) of the "Yellow" lead on the bulb socket connector.



OUT OF SPECIFICATION




The wiring circuit from the main switch to the bulb socket connector is faulty, repair it.

This circuit is not faulty.



# YFA1(P) 2002 WIRING DIAGRAM



- ① AC magneto
- ② Rectifier/regulator
- ③ Main switch
- ④ Fuse
- ⑤ Battery
- ⑥ Starter relay
- ⑦ Starter motor
- ⑧ Starting circuit cut-off relay
- ⑨ CDI unit
- ⑩ Ignition coil
- ⑪ Spark plug
- ⑫ Neutral indicator light
- ⑬ Neutral switch
- ⑭ Reverse switch
- ⑮ Reverse indicator light
- ⑯ Reverse relay
- ⑰ Brake lever switch
- ⑱ Front brake light switch
- ⑲ Tail/brake light
- ⑳ Handlebar switch (left)
- ㉑ Lights switch
- ㉒ Engine stop switch
- ㉓ Start switch
- ㉔ Headlight

## COLOR CODE

B ..... Black  
 Br ..... Brown  
 L ..... Blue  
 O ..... Orange  
 R ..... Red  
 Sb ..... Sky blue

W ..... White  
 Y ..... Yellow  
 G/L ..... Green/Blue  
 G/W ..... Green/White  
 G/Y ..... Green/Yellow  
 L/W ..... Blue/White

R/B ..... Red/Black  
 R/W ..... Red/White  
 W/L ..... White/Blue  
 W/R ..... White/Red  
 Y/R ..... Yellow/Red